

Instruction to substitute the mask tempered glass with optical lens on the Angel mask

1. Put the extremity of a little flat screwdriver between the main frame and the inner frame near to the the hooking tooth in the nose area and lever till the inner frame exits (pict.A)



Pict.A

2. Do the same close to the hooking teeth all around (Pict.B and pict.C)



Pict.B



Pict.C

3. Now strongly hold with the fingers the lateral side of the inner frame and extract it (pict. D and E).



Pict.D



Pict.E

4. Extract the glass from his seat (pict. F) and substitute it with the optical lens (the flat surface outside and the curved surface inside).



Pict.F

- 5. Re-put the inner frame in his seat (pict. G) and hang the teeth all around. For this operation you can help yourself using a clamp (pict. H and I). to do this operation be careful to avoid to damage the plastic parts.
In order to avoid scratches, you can wrap the clamp lips with electric tape.**



Pict.G



Pict.H



Pict.I

To be sure about the sealing of the mask, place it on a table and put inside few cl of water: if after few minutes the mask doesn't leak, job is done properly.

